

Waste Tape Expeller TNS

Designed to remove the waste tape after the cutting and bending operation, it is assembled on the back of the Superform machines.

7915.080A
7915.080B

Expeller for SUPERFORM/A-AP-V-S-R-RCP
Expeller for SUPERFORMAF-/VP



TNS